

RickRak-Smartphone Connect Module Setup Guide

For Apple CarPlay and Android Auto

Before You Begin

- Ensure your motorcycle is turned off.
 - Have your Smartphone Connect Module ready.
 - Make sure Bluetooth is enabled on your smartphone.
-

Step 1: Start the Motorcycle

1. Turn the motorcycle on.
 2. Allow the infotainment screen to fully boot up before continuing.
-

Step 2: Connect the Smartphone Connect Module

1. Plug the Smartphone Connect Module into the motorcycle.
 2. Wait several minutes for the module to power up.
-

Step 3: Allow Initial Calibration

1. A pop-up labeled "**Android**" should appear on the screen.
 2. The display may then show a blue screen indicating that it is **restarting for screen calibration**.
 3. The screen may briefly turn off during this process.
 4. This is normal—do not disconnect the module or turn off the motorcycle.
-

Step 4: Return to the Main Menu

1. After the calibration process is complete, return to the motorcycle's main menu.
2. The system will reload and display the "**Android**" prompt again.

Step 5: Select Your Device Type

1. A setup screen will appear.
2. Choose the option that matches your phone:
 - o **Apple CarPlay** (iPhone)
 - o **Android Auto** (Android)

Step 6: Pair Your Smartphone

1. The screen will display a Bluetooth ID or device name for the Smartphone Connect Module.
2. Open the Bluetooth settings on your phone.
3. Search for available devices.
4. Select the Bluetooth ID shown on the motorcycle's screen.
5. Follow any pairing prompts on both the phone and the motorcycle display.

Step 7: Complete the Connection

1. Once pairing is complete, the module will connect to your phone.
2. Apple CarPlay or Android Auto will launch on the motorcycle's display.
3. You can now access compatible apps, navigation, music, calls, and other supported features directly from the screen.

Important Notes

- The initial startup and calibration process may take several minutes.
- Do not disconnect the module during setup.
- Keep the motorcycle powered on until installation and pairing are complete.
- Bluetooth must remain enabled on your smartphone for pairing.

Setup Complete!

Your Harley-Davidson infotainment system is now ready to use Apple CarPlay or Android Auto.